


## AZ4467/AZ4468 INSTRUCTION

### Warning:



1. Please read this manual carefully and keep it accessible for further reference
2. Please switch off the power before doing any work.



### Safety Messages:

1. When installing, please conforms to the instruction of equipment, and installed by professionals.
2. Before installing, please check the products whether affected with dirty, damp or not.
3. Anything of the lights cannot be changed at random.
4. This instruction is suitable for AZ4467 and AZ4468 series.

### Basic product information:

ITEM CODE	Rated Wattage	Rated Voltage	IP	
AZ4467 AZ4468	6W	AC220-240V	<b>65</b>	

### Installation

1. Take the light out of the package, check the lamp. If there is any broken on the housing, should view it as disqualified product, and should not use it
2. Tighten the spike to the lamp head by hand screw, and then fix the lamp into the ground. See Picture 1
3. Connect the brown cable to L, blue cable to N, yellow and green cable to see picture 2
4. When connecting the cable, please use waterproof connector,
5. Turn on the power
6. Adjust lamp head to the direction you want to light up, see picture 3

